
17x2 UNDER FLOOR UNION FOR PIPE CONNECTION





Product Name Under Floor Union for Pipe Connection Intended Use Installation Systems

DIMENSIONS		
Code	06.01.317	
D1(thread)	1/2"	
D2(thread)	M23X1,5	
AA1	25	
AA2	26	
L1	16	
L2	38,5	



MATERIAL PROPERTIES	
BODY	BRASS (CW617N)/(CW614N)
NUT	BRASS (CW617N)/(CW614N)
RING	BRASS (CW617N)/(CW614N)
TIP	BRASS (CW617N)/(CW614N)
TIP-ORING	NBR

SURFACE PROPERTIES	
TIP	NICKEL
NUT	NICKEL





INSTALLATION and OPERATING INSTRUCTION

- **1-** Do not unpack the valve until installation to prevent falling of any unwanted substance that may affect the working of valve.
- 2- Take measures againts any possible damage thay may occur during transport and shipment.
- 3- Clean away every unwanted substance in your system before installation.
- 4- Valve sholud be off position while intalling.
- **5-** Be careful that the thread length of the part that will be installed to the valve will not be too longer or too shorter than the thread length of the valve.
- 6- While installing, grab the valve by the appropriate tool from the across flats where you'll install it.
- 7- During installation do not use excessive adhesive or any unsuitable substance.
- 8- Use the valve fully open or fully closed position.
- **9-** Do not paint the valve. Do not expose the valve with abbrasive chemicals.
- 10- Do not use any other tools for opening or closing the valve and do not remove the handle.
- 11- In case of any damage or disorder, valve should be changed by authorities.
- **12-** Complying with the installation and usage instruction is compulsory. Otherwise, the product will be cut of guarantee.
- 13- Do not forget to get the document of guarantee. This document is valid only with the related bill.