16x2 UNDERFLOOR UNION FOR PIPE CONNECTION










TECHNICAL DATA SHEET

Product Name	Underfloor Union For Pipe Connection

Intended Use Installation Systems

DIMENSIONS	
Code	06.02.315
D1	1/2"
D2	1/2"
AA1	24
AA2	24
L1	14,1
L2	33,5



MATERIALS	
BODY	BRASS (CW617N)/(CW614N)
NUT	BRASS (CW617N)/(CW614N)
RING	BRASS (CW617N)/(CW614N)
FRONT TAIL	BRASS (CW617N)/(CW614N)
FRONT TAIL O-RING	NBR

MATERIALS	
Ring	NICKEL
NUT	NICKEL





INSTALLATION and OPERATING INSTRUCTION

- **1-** Do not unpack the valve until installation to prevent falling of any unwanted substance that may affect the working of valve.
- 2- Take measures againts any possible damage thay may occur during transport and shipment.
- 3- Clean away every unwanted substance in your system before installation.
- 4- Valve sholud be off position while intalling.
- **5-** Be careful that the thread length of the part that will be installed to the valve will not be too longer or too shorter than the thread length of the valve.
- 6- While installing, grab the valve by the appropriate tool from the across flats where you'll install it.
- 7- During installation do not use excessive adhesive or any unsuitable substance.
- 8- Use the valve fully open or fully closed position.
- 9- Do not paint the valve. Do not expose the valve with abbrasive chemicals.
- 10- Do not use any other tools for opening or closing the valve and do not remove the handle.
- 11- In case of any damage or disorder, valve should be changed by authorities.
- **12-** Complying with the installation and usage instruction is compulsory. Otherwise, the product will be cut of guarantee.
- 13- Do not forget to get the document of guarantee. This document is valid only with the related bill.