




TECHNICAL DATA SHEET	
Product Name	3/8" Mini Brass Ball Valve
Working Temperature	-10°C to 100°C
Working Pressure	10 Bar
Intended Use	Air / Water Installation

DIMENSIONS	
Code	05.03.321
D1	3/8"
D2	3/8"
SW (mm)	21
L1 (mm)	32
L2 (mm)	40,6
H1 (mm)	10,5
H2 (mm)	30,4
Dimensions are in "milimeter"	





3/8" Mini Brass Ball Valve



PART NAME	MATERIAL
Body	Brass (CW617N)/ (CW614N)
Ball Seal	PTFE (Teflon)
Stem	Brass (CW617N)/ (CW614N)
Stem Seal	NBR (0-Ring)
Ball	Brass (CW617N)/ (CW614N)
Handle	Plastic

SURFACES FINISH	
Body	Nickel
Stem	
Ball	Nickel + Chrome
Handle	Plastic (Different Color Option)

INSTALLATION and OPERATING INSTRUCTION

- **1-** Do not unpack the valve until installation to prevent falling of any unwanted substance that may affect the working of valve.
- 2- Take measures against any possible damage that may occur during transport and shipment.
- **3-** Clean away every unwanted substance in your system before installation.
- 4- Valve should be off position while installing.
- **5-** Be careful that the thread length of the part that will be installed to the valve will not be too longer or too shorter than the thread length of the valve.
- 6- While installing, grab the valve but he appropriate tool from the across flats where you'll install it.
- 7- During installations do not use excessive adhesive or any unsuitable substance.
- **8-** Use the valve fully open or fully closed position.
- **9-** Do not paint the valve. Do not expose the valve with abbrasive chemicals.
- 10- Do not use any other tools for opening or closing the valve and do not remove the handle.
- 11- In case of any damage or disorder, valve should be changed by authorites.
- **12-** Complying with the installation and usage instruction is compulsory. Otherwise, the product will be out of quarantee.
- 13- Do not forget to get the document of guarantee. This document is valid only with the related bill.